## 4501 - Champ Hydraulic Side/End Lift



The basic lift will arrived already assembled. There is some minor assembly shown in these instructions.

**WARNING** 

Read all assembly instructions completely before using lift. Follow all instructions. Failure to so could result in damage to lift or vehicle or injury to user. Do not exceed weight capacity of 3,00lbs.

1.




The jack beam adapter has a slot one side.

2\_



The adapter attaches to the cross beam adapter with the supplied bolt.

3.



Tighten bolt securely.

4.



Slide the assembled adapter into the lift beam of the lift. Lock it into place with the supplied locking pin.

**5.** 



Your lift is now ready to use. Make sure that the lift pads are placed in an approved lifting section of the car. Contact the vehicle manufacturer if you are not sure where to place the lifting pads.